


DPP-255 Mobile Printer

QUICK START GUIDE



CHARGING

1. Pull the DC Jack Port cover tab back and insert the AC adapter into the port.
2. Insert the AC adapter plug into an outlet to begin charging.



INSTALLING PAPER ROLL

1. Press the Paper Cover Release button to open the cover.
2. Gently pull the paper guides apart and insert the paper roll so that the end of the paper roll faces the back of the printer and comes up from the bottom of the compartment.
3. Pull the end of the paper roll so that it is sticking slightly outside of the paper feed area and close the cover.



PEELER UNIT (LABELS)

1. Insert the label stock into the printer with the end of the label roll sticking out of the feeder approximately 1-1/2 inches (40 mm). Close the cover.
2. Raise the peeler unit arm and pull the label-end toward the back of the printer.
3. Lower the peeler unit to secure the label stock place.
4. Press the Feed button on the front of the printer to set the position of the label paper.

