




mPOS



mPOS Flat



**Infinea® mPOS
Charging Station
(1-Unit)**

QUICK START GUIDE

mPOS




mPOS Flat



ASSEMBLY

1. Place the Infinea mPOS Charging Station on a sturdy, clean and dry surface in an open, well-ventilated area away from direct sunlight.
2. Insert the USB plug into the USB port on the charger. Connect the other end of the USB cable to a PC USB port or USB 5V power adapter.
3. Insert the Infinea mPOS unit into a charging bay, ensuring that the battery contacts are aligned with the bay's contacts. The LED will light up to provide the charging status.



CHARGE STATUS

The Infinea mPOS Charging Station uses the following LEDs to indicate the charge status:

STATUS INDICATOR LEDES	
Green	Inserted device is fully charged.
Orange	Inserted device is charging.
No LED	Indicates there is no device in charging bay or there is no power supply attached the charger.

TROUBLESHOOTING

The LED does not come on when the Infinea mPOS is inserted into the charging station.

- Ensure that the USB cable is securely inserted into the USB port on the charging station and connected to the PC USB or USB 5V power adapter
- Ensure the unit is seated properly in the charging bay

It takes an excessive amount of time to fully charge the battery.

- Verify ambient temperature meets the operating temperature requirements
Operating: 0°C - 40°C (32°F - 104°F)

